




INVERSION PREVENTER PIN - IMPORTANT NOTICE



To limit the spreader from swinging too far forward (inverting), a clevis pin is fitted. The pin is usually fitted in the aft spreader bracket hole (as shown).

If your spreaders have a large sweep angle, and the central hole is unobstructed, fit the clevis pin there.

INVERSION PREVENTER PIN - IMPORTANT NOTICE