



Locking

Locked

Unlocking

The 2mm wire main halyard has a 2mm Talurite ferrule as it's stop.

To lock, the sail is hoisted. As it reaches the desired position, the talurite stop runs down over the "ramp", and locates in the step. It is visible on the outside of the mast.

To unlock, halyard is pulled until the stop reaches the lock's base. The stop then moves aft, enters a wide internal groove, and runs back upwards inside the lock body.